


R02

Направляющие колонки

Материал: сталь 1.7131



Пример заказа (R02 + L + D + L1): **R0201209025**

L	D		L1														d1	d2	k	B
			020	025	030	035	045	050	055	060	065	070	075	085	090	095				
012	09	10															14	16	3	3
017																				
022																				
027																				
036																				
046																				
056																				

L	D		L1																		d1	d2	k	B	
			030	035	045	050	055	065	070	075	085	090	095	105	110	125	135	145	150	155					165
017	14	15																			20	16	3	3	
022																						20	25	6	9
027																									
036																									
046																									
056																									
066																									
076																									
086																									
096																									
116																									


L	D		L1																	d1	d2	k	B	
			035	045	055	065	075	085	095	105	115	120	125	135	145	155	165	225	245					255
017	18	20																			26	31	6	9
022																								
027																								
036																								
046																								
056																								
066																								
076																								
086																								
096																								
116																								
136																								

CAD reference point

Направляющие колонки

R02

Материал: сталь 1.7131


Пример заказа (R02 + L + D + L1): **R0201722035**

L	D	L1																		d1	d2	k	B
		035	045	055	065	075	085	095	105	115	125	130	135	145	155	165	205	245	285	30	35	6	9
017	22 24																						
022																							
027																							
036																							
046																							
056																							
066																							
076																							
086																							
096																							
116																							
136																							
156																							

L	D		L1																		d1	d2	k	B			
			45	55	65	75	85	95	105	115	125	135	155	165	175	185	205	195	225	245					285	295	
027	30	32																					42	47	6	9	
036																											
046																											
056																											
066																											
076																											
086																											
096																											
116																											
136																											
156																											
196																											

L	D	L1										d1	d2	k	B
		075	095	115	135	155	165	175	195	215	235				
046	40 42											54	60	10	12
056															
066															
076															
086															
096															
116															
136															
156															
196															
246															

CAD reference point